Digital Camera

FinePix F650 Quickstart

FUJIFILM digital

Camera Controls





BL00542-200(1) E

Picture Taking

Refer to Owner's Manual for more detailed instructions

A. Charging the Battery

1. 

Plug the Battery Charger BC-40 (included) into the power outlet using the connection cord.

2. **Charging lamp**



Load the battery into the Battery Charger BC-40 correctly as indicated by the polarity icon to start charging. Charging ends after about 90 minutes and the charging lamp turns off. Unplug the battery charger from the power outlet when it is not in use.

B. Loading the Battery



Hold the battery so that the indicators are aligned. Push the battery release catch aside while loading the battery. Check that the battery is firmly held in place.

C. Setting up the Camera

1.

Press POWER button down fully to turn the camera on.

2. 

"DATE/TIME NOT SET" message appears when turning the camera on.

3.

Press MENU/OK to set the date and time.

4.

You can select your preferred date format.

5.

Press ◀ or ▶ to select Year, Month, Day, Hour, or Minute. Press ▲ or ▼ to correct the setting.

✻ Refer to the Owner's Manual for "Turning On and Off".

D. Taking Pictures

1.

Press POWER button down fully to turn the camera on.

2. 

Set the Mode dial to .

3. 

Halfway pressed

Press the shutter button down halfway to adjust the focus.

4. 

Fully pressed

Press the shutter button down fully to take a picture. The camera makes a "Click" sound and takes the picture.

E. Viewing the Images

1.

Press .

2.

Press ◀ or ▶ to move through your images.

FinePix F650 has internal memory that can store images without **xD-Picture Card**. Use an **xD-Picture Card** (sold separately) when recording a large number of images.

Still images that can be viewed on FinePix F650

You can use this camera to view still images recorded on FinePix F650 or still images (excluding some uncompressed images) recorded on a FUJIFILM digital camera that supports **xD-Picture Card**.

Downloaded From camera-usermanual.com Fujifilm Manuals

Viewing Images on your PC

A.Installing Software



B.Connecting the Camera to your PC

C.Saving Images



A. Installing Software

Do not connect the camera to your PC until the software installation is completed.

1. Turn on your PC and start up Windows.
   - Users of Windows 2000 Professional or Windows XP should log in by using a system administrator account (e.g. "Administrator").
2. Quit all other active applications until no applications are shown in the taskbar.
3. Load the enclosed CD-ROM into the CD-ROM drive. The installer starts up automatically.
4. The Setup screen appears. Click the [Installing FinePixViewer] button.



5. After installation completed, press [Close] button.

B. Connecting the Camera to your PC

1. Insert the **xD-Picture Card** with images into the camera.
2. Press ▶ for about 1 second to turn the camera on in Playback mode.

   

   Select DSC in USB MODE in the SET-UP menu.

   Refer to the Owner's Manual for "Using the SET-UP menu".
3.

   Press POWER button to turn the camera off.
4. If you have one, plug the AC power adapter connector into the "DC IN 5V" socket on the camera and then plug the adapter itself into the main power outlet, otherwise be sure your battery is fresh and charged.
5. Connect the camera to your PC using the USB cable (included).



6. Press ▶ for about 1 second to turn the camera on in Playback mode.
7. Windows 98/98 SE/Me/2000 Professional

   FinePixViewer starts up automatically.

Windows XP

The "Found New Hardware" help message appears in the bottom-right corner of your screen. This message will close when the settings are completed. No action is required.

FinePixViewer starts up automatically.



C. Saving the Images

1. The Save Image Wizard starts up. Click the [Start] button.
2. Check that the files are downloaded from the camera to your PC and that a folder with the date is created.
   Ex. \My Documents \ My Pictures \ 2006_0524

D. Viewing the Images

1. Click the [Show List of Images] button.

2. Select "Preview" in the View menu to display an enlarged image.

For more information

Refer to "How to use FinePixViewer" in the HELP menu, or "Software Installation" in the Owner's Manual, or visit Fujifilm "Q&A Search" in the following website.
(**http://home.fujifilm.com/products/digital/**)
For Macintosh users, refer to "Software Installation" in the Owner's Manual.

Downloaded From camera-usermanual.com Fujifilm Manuals